## Standing lamp 3 rotating arms



120V / 60 Hz 3x60W incandescent

Suitable for indoor use only. Maximum ambient temperature 25°C.

To prevent electric shock, match wide blade of plug to wide slot. Smooth wire : connect to the line Ribbed wire : connect to the neutral

If the external flexible cable or cord of this luminaire is damaged, it must be exclusively replaced by the manufacturer to avoid any hazard.

Unplug the lamp before changing the bulbs.


## Instructions Standing lamp 3 rotating arms

## Unpack without using any cutter or scissor because of possible scratches.

1. Unpack the foot and the lower part of the central mast. Fit the mast to the foot.



2. Very important : screw the screw until blocking without deforming the tube.



3. Unpack the end of the arms to fit them to the central mast. Remove the cable protective caps in red plastic from the tubes. Release the packaging of reflectors without removing it completely.

4. At this stage, at least 2 operators are necessary. Pull gently the principal electrical cable out of the bottom of the central mast into fitting the 3 arms to the central mast.

5. Remove completely the packaging.

6. Before moving the arms, the screw must not be tightened otherwise painting could be damaged.





